COFFEE MACHINE

Low water level
The light indicates the water tank needs to be re lled.

Grounds container full
The indicator light warns that coffee grounds need to be removed from their container.

Replace lter
The indicator light informs the lter needs to be replaced.

Clean function
It starts the machine's clean cycle.

Steam dispenser
To heat various type of beverages.

Hot water dispenser
It can be used to prepare various types of beverages.

"Ristretto" dispenser
It dispenses "ristretto" espresso (the quantity of the shot can be set).

"Lungo" dispenser
It dispenses "lungo" espresso (the quantity of the shot can be set).

Strength adjuster
You can choose from three types of coffee: light, medium and strong.